

Vehicle information

Chrysler Up to 2003

VIN: 1C4GP45R15B196244

Diagnostics time: 2011/11/26 01:52

Mileage:

Path: Automatic selection > 2005 > RS-Caravan, voyager, town & country > Diagnosis > Auto scan > Active test > Auto shutdown relay >

Auto shutdown relay

Auto shutdown relay	Actuator has stoped!	
MAP VACUUM	1.5	mmVAC
MAP VOLTS	4.45	VOLTS
BAROMETRIC PRESSURE	763.9	Mm hg
P-RATIO MAP/BARO	0.99	%
TPS VOLTS	0.01	VOLTS
TPS CALCULATED VOLT	1.2	VOLTS
MINIMUM TPS	1.22	VOLTS
TPS PERCENT	0	%
CAM CRANK DIFFERENCE	0.0	
ENGINE RPM	0	RPM
TARGET IDLE	1200	RPM
TIME FROM START/RUN	0.0	MINs
IGNITION OFF TIME	0	Minutes
PURGE DUTY CYCLE	0	%
DES PURGE CURRENT	0	mA
ACT PURGE CURRENT	1	mA
PURGE AIRFLOW	0.0	gm/sec
PURGE MODE	OFF	
PURGE VAPOR RATIO	20.3	%
PURGE ADAPTIVE	0.0	%
EGR SENSE VOLTS	4.5	VOLTS
EGR DUTY CYCLE	0	%
EGR FLOW	0.0	gm/sec
INJECTOR PW CYL 1	0.0	mSEC
CRANKING INJ PW	0.0	mSEC
1/1 O2S GOAL VOLTS	0.0	VOLTS
1/1 O2 GOAL (0-1)	0.0	VOLTS
1/1 O2 VOLTS (0-1)	2.39	
1/2 O2 VOLTS (0-1)	2.31	

1/1 O2S VOLTS	4.94	VOLTS
1/2 O2S VOLTS	4.87	VOLTS
1/1 PWM O2 HEATER	0	%
1/2 PWM O2 HEATER	0	%
1/1 SHORT TERM ADAP	-0.0	%
1/1 LONG TERM ADAP	0.0	%
CLOSED LOOP TIMER	90.4	SECS
CURRENT ADAP CELL ID	24	
DES PWM RAD FAN	0	%
ENG COOLANT TEMP DEG	18.0	°C
ENG COOLANT TEMP VOLT	3.88	VOLTS
INTAKE AIR TEMP DEG	20.0	°C
INTAKE AIR TMP VOLT	5.01	VOLTS
BAT TEMP DEG	20	°C
BAT TEMP VOLT	2.2	VOLTS
AMB TEMP DEG	20	°C
AMB TEMP VOLT	2.23	VOLTS
CAT MODELED TEMP DEG	-64.0	°C
VOLTAGE SENSE	12.11	VOLTS
VOLTAGE SENSE	12.11	VOLTS
TARGET CHARGING VLT	13.75	VOLTS
GENERATOR DUTY CYCLE	0	%
IAC CURRENT	0	mA
IAC TOTAL AIRFLOW	5.9	gm/sec
IAC PWM	44.0	%
SPARK ADVANCE	0	
IGN DWELL CYL 1	0.0	mSEC
COIL 1 BURN TIME	0	uSECS
NVLD PULLDOWN TIMER	0.0	SECS
AC HI-SIDE PRESSURE	400	KPa
AC HI-SIDE VOLTS	0.73	VOLTS
FUEL LEVEL	26.5	LTR
FUEL LEVEL PERCENT	34	%
FUEL VAPOR VOLUME	64.4	LTR
FUEL TANK SIZE	78.6	LTR
FUEL LVL CALCULATED	-64.4	LTR
PCM ODOMETER	251321.7	Kilometers
VEH SPEED SIGNAL	0	km/h

S/C SWITCH VOLTS	4.55	VOLTS
S/C SET SPEED	0	km/h
S/C CANCEL SW	Released	
CURRENT FUEL SHUTOFF	ASD	
VEH THEFT SECURITY	FUEL ON	
VEH THEFT STATE	SEEN	
CAM SYNC STATE	Out-Of sync	
CAM SYNC AT START	Out-Of sync	
CRANK SYNC STATE	Out-Of sync	
CRANK SYNC AT START	Out-Of sync	
CAM CRANK LAST LOST		
FUEL FEEDBACK 1/1		
BRAKE SWITCH		
P/N POSITION SW		
A/C SELECT SWITCH		
DES AC CLUTCH RELAY		
ACT AC CLUTCH RELAY		
OIL PRESSURE SW		
ASD RELAY SENSE		
DES ASD RELAY		
Fuel pump relay		
DES DOUBLE START OV		
IGN START SW SENSE		
IGN RUN SW SENSE		
DES MALFUNCTION LAMP		
NVLD SWITCH		
DES NVLD SOLENOID		
S/C CRUISE IND LAMP		
S/C ON/OFF SW		
S/C SET SW		
S/C ACC/RES SW		
S/C COAST SW		
S/C CANCEL SW		
DES S/C VAC SOL		
DES S/C VENT SOL		
S/C DUMP		
S/C WORKING STATUS		
S/C DENIED STATUS		